



Note

1. Pass the lead through the terminal and round it wind the lead to solder it.
2. After soldering, the lead must be equipped as this drawing shows.
3. Take the following steps.
 - 3-1) Remove a clamp of item 12 with care of not damaging the harnesses.
 - 3-2) Clamp the lead 20 ± 5 mm from the uncoverd as this drawing shows.

CONFIDENTIAL

T966 (MA-21D5) SW UNIT Drawing